




CSA Baseline




CSA K







Good event




Bad event




CSA 32x32




Slow shaper Baseline




Slow shaper max. sig amp




Slow shaper chi2




Slow shaper nonlinearity







Slow shaper noise







Slow shaper SNR







Fast shaper baseline



Fast shaper chi2



Fast shaper K



Fast shaper SNR

