


Studies on ECAL sampling and shower reconstruction

Andrei Maltsev

SPD Physics & MC meeting
22.07.2020

Sidenote: ECAL simulation in SPDROOT

- Endcaps (SpdEcalQEC): construction/simulation implemented, to be integrated into SPDROOT very soon
- Barrel: module placement algorithm to be finalized (this week) (optimize cell size to avoid gaps)




Picture of O.P.Gavrishchuk
Equal-sized modules:
not the most optimal setup?

also consider space for electronics?
(how large is ECAL-RS gap?)


ECAL sampling studies

- Standard sampling: 0.5mm lead + 1.5mm scintillator
x 200 layers




Energy resolution at 300-400 MeV:
~12%
too bad for χ_{c1}/χ_{c2} analysis


ECAL sampling studies




SPD ECAL resolution




SPD ECAL resolution




SPD ECAL resolution




SPD ECAL resolution



SPD ECAL resolution



Effect of cell threshold on resolution





NO CORRECTION
30 MeV THRESHOLD
50 MeV THRESHOLD
70 MeV THRESHOLD

**for low energies,
low threshold is
very important**


Shower reconstruction

- Lednev's method: NIM A 366 (1995) 292-297
- Determine transverse shower shape using data:
 - 1) correct transverse position of shower



Shower reconstruction



- Lednev's method: NIM A 366 (1995) 292-297
- Determine transverse shower shape using data:
 - 2) determine cumulative energy distribution across transverse variable



3) use the cumulative distribution to fit showers in data



Shower reconstruction

- Lednev's method: NIM A 366 (1995) 292-297
- Determine transverse shower shape using data:



Shower reconstruction


- Lednev's method: NIM A 366 (1995) 292-297
- Determine transverse shower shape using data:




Conclusions

- ECAL simulation in SPDROOT will be ready soon (worst case - next week)
- Lower cell energy threshold would significantly improve energy resolution at low energies
- Finer sampling with increasing number of layers (same module length) would be favourable for low energy resolution
- Fitting algorithm requires further work


BACKUP




SPD ECAL resolution




SPD ECAL resolution



SPD ECAL resolution



SPD ECAL resolution



SPD ECAL resolution

